

# ***GUNNAIL***™

取扱説明書

# GUNNAIL™

## 取扱説明書

### 注意事項 Technical information

#### (1)電源

Required Power Capacity  
+5V 5A or more  
+12V 1A or more

#### (2)Output

R—analog, positive  
G—analog, positive  
B—analog, positive  
SYNC—H-V complexed, negative




### あそびかた Play Instruction

半田面 SOLDER SIDE			部品面 COMPONENT SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
	E	5	
+12V	F	6	+12V
	H	7	
COIN COUNTER2	J	8	COIN COUNTER1
	K	9	
SP(-)	L	10	SP(+)
	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
	S	15	
COIN SW 2	T	16	COIN SW 1
START SW 2	U	17	START SW 1
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P PUSH 1	Z	22	1P PUSH 1
2P PUSH 2	a	23	1P PUSH 2
	b	24	
	c	25	
	d	26	
GND	e	27	GND
GND	i	28	GND

### JAMMA仕様

#### ◎操作



#### ◎アイテム ITEMS



(青) ワイドショット 広範囲に攻撃可能  
WIDE SHOT wide attack



(紫) レーザー 攻撃力の高い武器  
LASER Big destructive power weapon



(赤) ファイアービーム 敵にロックする追尾ビーム  
FIRE BEAM Lock on enemies



亜空間ボム  
SPATIAL BOMB

敵に大ダメージを与える  
Big damage to enemies



パワーアップ  
POWER-UP

10段階にパワーアップ  
10 kinds of step



スーパーアクセル  
SUPER ACCELERATOR

加速中は得点が2倍  
Double score under acceleration



ボーナスアイテム  
BONUS ITEM

面クリア時にボーナス  
Special bonus at stage clear

2P同時プレイ コンティニュー・途中参加可能  
1P 2P PLAY POSSIBLE AT THE SAME TIME  
PARTICIPATION POSSIBLE ON THE WAY

50万・200万点でシールドゲージが1つ増え更に全回復する  
YOU HAVE STILL ONE MORE SHIELD GAUGE AT 500,000  
POINTS & 2,000,000 POINTS, AND HAVE A COMPLETE  
RECOVERY FROM ANY DAMAGES.

# GUNNAIL

## ディップスイッチ DIP SWITCH

DIP SWITCH 1		1	2	3	4	5	6	7	8
難易度 DIFFICULTY	普通 NORMAL					OFF	OFF		
	易しい EASY					ON	OFF		
	難しい HARD					OFF	ON		
	非常に難しい HARDEST					ON	ON		
画面反転 SCREEN F/F	無し NO								OFF
	有り YES								ON
出荷時の設定 SETTING AT MAKER'S DELIVERY		OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

DIP SWITCH 2		1	2	3	4	5	6	7	8
COIN SW 1	1 COIN 1 PLAY	OFF	OFF	OFF					
	1 COIN 2 PLAY	ON	OFF	OFF					
	1 COIN 3 PLAY	OFF	ON	OFF					
	1 COIN 4 PLAY	ON	ON	OFF					
	2 COINS 1 PLAY	OFF	OFF	ON					
	3 COINS 1 PLAY	ON	OFF	ON					
	4 COINS 1 PLAY	OFF	ON	ON					
	FREE PLAY	ON	ON	ON					
COIN SW 2	1 COIN 1 PLAY				OFF	OFF	OFF		
	1 COIN 2 PLAY				ON	OFF	OFF		
	1 COIN 3 PLAY				OFF	ON	OFF		
	1 COIN 4 PLAY				ON	ON	OFF		
	2 COINS 1 PLAY				OFF	OFF	ON		
	3 COINS 1 PLAY				ON	OFF	ON		
	4 COINS 1 PLAY				OFF	ON	ON		
	FREE PLAY				ON	ON	ON		
デモ時のサウンド DEMONSTRATION SOUND	有り YES							OFF	
	無し NO							ON	
出荷時の設定 SETTING AT MAKER'S DELIVERY		OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

921008

